

Use as a Single Shot Rifle

Turn the gas plug so that the letters "Gr" appear on top, instead of the letter "A".

With the magazine removed, pull the cocking handle fully back.

With the right hand, push the holding open device upwards (fig. 22). Keeping it in this position, let the mechanism come gently forward until it stops against the holding open device, which keeps the mechanism in its rear position; the gun is then in the open position.

Still using the right hand, insert a round into the chamber, pushing it fully home with the thumb.



Fig. 22

Press the holding open device downwards (as if loading by magazine) the mechanism will then move forward, impelled by the return springs, and the rifle is ready to fire.

The same operation then must be repeated for each round.